


LUXONUM GmbH
Im Buchwald 65
70186 Stuttgart, Germany

Support and help:
www.luxonum.com
contact@luxonum.com


© 2020 LUXONUM GmbH



1. Turn on or off, dimming



2. Exchange the stone cube



3. Exchange LED bulb

Remove stone as described above.

Remove bulb by pulling vertically and replace with a new one.

Allowed bulbs: Socket G4, LED, MAX 3.5 W, DIMMABLE

